


SVELTE RGBW



CAUTION - Must Be Installed By A Licensed Electrician Only.


 Please read the instructions for the installation of fixture provided below. Warranty will be void unless followed.


220-240 V~50/60Hz


- The installation and operation of this fixture must be in accordance with the national safety regulations. L'azure is not liable when damage is caused due to improper installation.
- Please read the detailed product specification sheet available at www.lazurelighting.com for any technical information regarding the fixture.

19 Watts / Meter


 Over-voltage protection units should be installed inorder to prevent electronic and electrical components from failing due to voltage spikes.









IP20 / IP65 / IP68







Disclaimer: 1. Due to continuous product improvement the installation method is subject to change.

Images and procedures are for representation and reference purpose only.